



# Escort Elf<sup>®</sup> Pump

## instruction manual

### **⚠ WARNING**

**THIS MANUAL MUST BE CAREFULLY READ BY ALL INDIVIDUALS WHO HAVE OR WILL HAVE THE RESPONSIBILITY FOR USING OR SERVICING THE PRODUCT. Like any piece of complex equipment, this product will perform as designed only if it is used and serviced in accordance with the manufacturer's instructions. OTHERWISE, IT COULD FAIL TO PERFORM AS DESIGNED AND PERSONS WHO RELY ON THIS PRODUCT FOR THEIR SAFETY COULD SUSTAIN SEVERE PERSONAL INJURY OR DEATH.**

The warranties made by Mine Safety Appliances Company with respect to the product are voided if the product is not used and serviced in accordance with the instructions in this manual. Please protect yourself and others by following them. We encourage our customers to write or call regarding this equipment prior to use or for any additional information relative to use or repairs.

In the U.S., to contact your nearest stocking location, dial toll-free 1-800-MSA-2222.

To contact MSA International, dial 1-800-672-7777.

© Mine Safety Appliances Company 2007 - All Rights Reserved

PRODUCT OF U.S.  
MINE SAFETY APPLIANCES COMPANY  
P.O. Box 427, Pittsburgh, Pennsylvania 15230

## **⚠ WARNINGS**

1. Do not charge the battery pack in areas that may contain a flammable mixture of combustible gases, vapors, or dust and air; otherwise, an explosion may occur because a source of ignition exists during charging.
2. Do not operate the pump in oxygen-enriched atmospheres (more than 21% oxygen) containing combustible gases, vapors, or other materials. Fire or explosion can result from operating in these atmospheres.
3. Operate the pump with MSA P/N 10087242 battery pack only. Do not use other batteries or power sources.
4. When using the pump in a hazardous area (with respect to fire or explosion) as specified in the National Electric Code (NEC) Article 500 - Hazardous (Classified) Locations, the pump must be labeled stating that it meets the design criteria of the specific Class, Division and Group. Users must operate the pump in accordance with the instructions for that Class, Division, and Group. A copy of the NEC Code can be obtained from the National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.
5. Use only genuine MSA replacement parts when performing maintenance procedures described in this manual; failure to do so may seriously impair the ESCORT ELF Pump performance. Repair or alteration beyond the scope of these maintenance instructions or by anyone other than authorized MSA service personnel could cause the product to fail to perform as designed, and persons who rely on this product for their safety could sustain severe personal injury or death.

**FAILURE TO COMPLY WITH THE ABOVE WARNINGS CAN RESULT IN SERIOUS PERSONAL INJURY OR DEATH.**

## CAUTIONS

1. Do not use the pump with organic fluids in an impinger without an absorber trap; otherwise, the pump will be damaged.
2. Use only an MSA Omega ( $\Omega$ ) Charger to charge the pump.
3. If, after thoroughly reading this manual, you are uncertain of the installation, operation, or maintenance procedures, call 1-800-MSA-2222 for assistance.

## Table of Contents

<b>Section 1</b>	
<b>General Information</b> .....	<b>1-1</b>
Introduction .....	1-1
Operating Specifications .....	1-2
<b>Section 2</b>	
<b>Theory of Operation</b> .....	<b>2-1</b>
Introduction .....	2-1
Functional Description of Operation .....	2-1
Figure 2-1. Flow-Feedback Control System .....	2-2
LED Indicator Operation .....	2-3
<b>Section 3</b>	
<b>Operation</b> .....	<b>3-1</b>
Charging the Battery Pack .....	3-1
▲ WARNING .....	3-1
▲ CAUTION .....	3-1
Operating Time .....	3-1
Personal/Area Sampling .....	3-2
Figure 3-1. Typical Operating Time Graph .....	3-2
Operating the Pump .....	3-3
<b>Section 4</b>	
<b>Routine Maintenance</b> .....	<b>4-1</b>
Periodic Maintenance .....	4-1
Checking the Inlet Filter .....	4-1
Figure 4-1. Checking the Inlet Filter .....	4-1
Filter Replacement .....	4-2
Frit Replacement .....	4-2
Battery Pack Replacement .....	4-2
Figure 4-2. Replacing the Battery Pack .....	4-3

<b>Section 5</b>	
<b>ELF Sensor Calibration</b> .....	<b>5-1</b>
<b>Section 6</b>	
<b>ELF Sensor Calibration</b>	
<b>for Pumps used in the U.S. Government Mine Safety</b>	
<b>and Health Administration (MSHA) Coal Mine Dust</b>	
<b>Sampling Program</b> .....	<b>6-1</b>
<b>Section 7</b>	
<b>Repairs and Replacement Parts</b> .....	<b>7-1</b>
Troubleshooting .....	7-1
▲ WARNING .....	7-1
Corrective Maintenance .....	7-1
Table 7-1. Troubleshooting Guidelines .....	7-2
Unplugging the Electrical Connectors .....	7-3
Reattaching the Electrical Connectors .....	7-3
Pump & Drive Assembly, Outlet Dampener, or	
Pressure Sensor Replacement .....	7-4
Printed Circuit Control Board Replacement .....	7-4
Obtaining Replacement Parts .....	7-5
Figure 7-1. Replacement Parts .....	7-6
Table 7-2. Replacement Parts List .....	7-7
Figure 7-2. Replacement Parts (cont.) .....	7-8

# Section 1

## General Information

### Introduction

The ESCORT ELF Pump introduces a totally new, patented concept of flow control and flow readout (U.S. Patent 5,295,790). The heart of this new system is the electronic laminar flow sensor. The ELF sensor combines a laminar flow element and a differential pressure sensor to measure sample volume flow rate. This measure of flow rate is not affected by changes in sample loading or the other factors that affect rotameter-type indicators used in other pumps. The ELF sensor provides an electronic signal which is linearly related to flow rate. This signal is used in the pump control circuit to maintain the chosen flow rate constant to within  $\pm 2.5\%$  and is used in the readout circuit to allow the digital display of the actual flow rate to within  $\pm 0.1$  liters per minute (LPM).

The ESCORT ELF sensor and control circuitry are very stable both in storage and use. Together they form a secondary standard to maintain the calibration accuracy for at least 200 hours of pump usage. A built-in operating time totalizer helps remind the user of the total operating hours since the last calibration check was performed against a primary flow standard. This totalizer automatically resets to 0 when a calibration is performed. If the pump is used in the coal mine dust sampling program, these calibration checks should be done after each 200 hours of use. If the pump is used for OSHA compliance sampling, the recalibration should be performed monthly.

Section 1, General Information

<b>Operating Specifications</b>	
<b>ELECTRICAL CHARACTERISTICS</b>	
<b>POWER SUPPLY</b>	4.8-volt battery pack of four nickel-cadmium cells
<b>BATTERY PACK CAPACITY</b>	1.8 ampere hour
<b>BATTERY PACK RECHARGE TIME</b>	14-16 hours (overnight) with recommended chargers
<b>CHARGING TEMPERATURE</b>	10° to 30°C (50° to 86°F)
<b>TYPICAL BATTERY PACK LIFE</b>	300 or more charging cycles
<b>OPERATING AND PHYSICAL CHARACTERISTICS</b>	
<b>FLOW CONTROL</b>	Volumetric flow rate is controlled at the set-point with automatic compensation for battery voltage, altitude, temperature, and sample load changes
<b>OPERATING RANGE</b>	0.5 TO 3.0 LPM
	5 to 30 inches water load up to 1.0 LPM; up to 30 inches of water load up to 2.0 LPM; up to 20 inches of water load up to 2.5 LPM; and up to 10 inches of water load up to 3.0 LPM
<b>FLOW BLOCKAGE DETECTION</b>	When flow is blocked the FLOW FAULT LED indicator lights and stays lighted until the cause of flow blockage is removed. If blocked for longer than 1.5 minutes, the pump shuts down. Pumps that are ordered for coal mine dust sampling are factory-programmed to <i>not</i> shut down
<b>FLOW READOUT</b>	Liquid crystal digital display with 0.01 LPM resolution from 0.5 to 3.0 LPM
	Accuracy ±2.5% from 1.0 to 3.0 LPM, 0° to 45°C ±5% from 1.0 to 3.0 LPM, -20° to 0°C and 45° to 65°C ±5% from 0.5 to 0.9 LPM, 0° to 45°C

Section 1, General Information

<b>Operating Specifications</b>	
<b>ELAPSED TIME READOUT</b>	Quartz controlled timer reads out to 999 minutes in 1-minute steps. Holds last reading after either flow fault or low battery shut-down, and when pump is OFF or in HOLD mode; resets to zero automatically when pump is turned ON. Timer does not count time when FLOW FAULT LED is lighted.
<b>SCHEDULED CALIBRATION</b>	The pump has an operating hours totalizer to help remind user of the need for periodic calibration checks.
<b>OPERATING TIME</b>	Varies with flow rate, sampling device loading and temperature. Minimum eight-hour operation at 2.5 LPM with 20-inch water load. (See FIGURE 3-1.)
<b>LOW BATTERY FUNCTION</b>	The pump shuts down and lights the LOW BATT LED when battery voltage drops below 4.1 volts
<b>TEMPERATURE COMPENSATION</b>	0° to 45°C (32° to 113°F) ±2.5% accuracy -20° to 0°C and 45° to 65°C (-4° to +149°F and 112° to 148°F) ±5.0% accuracy
<b>ALTITUDE COMPENSATION</b>	Below sea-level to at least 10,000 ft.
<b>DIMENSIONS</b>	2 inches deep x 4 inches high x 3-7/8 inches wide (5.1 centimeters deep x 10.3 centimeters high x 9.8 centimeters wide)
<b>WEIGHT</b>	19 oz. (550 grams)
<b>CASE</b>	Case plastic is electrically conductive to reduce radio frequency interference; an optional leather case is available for pump protection during rough usage such as underground mining or construction and demolition work areas
<b>SERIAL NUMBER IDENTIFICATION</b>	Located on the side of the case under the battery pack (include number in correspondence with MSA)



## Section 2 Theory of Operation

### Introduction

This section describes the operation of the sample flow control and readout circuitry of the ESCORT ELF Pump.

### Functional Description of Operation

The ESCORT ELF Pump contains a rechargeable battery pack, a motor-driven pump, the ELF sensor, and the electronic circuit to control and display the flow rate.

The battery pack consists of four nickel-cadmium cells. The cells are connected in series with a current limiting resistor to allow use in hazardous atmospheres (see "Warnings"). The pack also has a PTC resistor which functions as a self-resetting circuit breaker to prevent damage to the pack if the output terminals are accidentally shorted.

The motor-driven pump consists of an inlet pulsation dampener, a diaphragm pump, and silicone rubber inlet and exhaust valves. The diaphragm is driven by the motor to make one pump stroke with each revolution. The pulsation dampener acts as an elastic storage chamber to smooth the individual pump pulses to minimize their effect on the sampling devices connected to the pump inlet.

The ELF sensor consists of a laminar flow element and a pressure sensor. All of the air flow through the pump passes from the exhaust port of the pump and through the laminar flow element. The element is a hollow cylinder of porous stainless steel. The air flowing through the narrow passages in the cylinder produces an air pressure difference between the outer and inner walls of the cylinder. This difference is monitored by

## Section 2, Theory of Operation

---




Figure 2-1. Flow-Feedback Control System

connections to the high and low pressure taps of a sensitive differential pressure sensor. The electrical signal from the sensor is a linear voltage, which is directly related to the air flow through the laminar element. This signal is compared to the flow set point in the electronic circuit and is used to control the flow at the set point. Any deviation in flow rate is sensed and the motor power is adjusted to maintain the preset flow rate. In the case of a blocked flow or operation beyond the pump capacity where the flow cannot be brought to within  $\pm 0.1$  LPM of the set point, the flow fault LED will be lighted.

### **LED Indicator Operation**

- The RUN/HOLD LED assures the user that the unit is operating, even in poorly lit, noisy environments.
- The RUN/HOLD LED also indicates the HOLD function. If the pump is switched to HOLD, the pump shuts down, the timer stops, and the LED is switched to a blinking mode. When the RUN/HOLD switch is pressed again, the pump will restart and the timer will continue from its "hold" value.
- The LOW BATT LED indicates operation of the low battery detection circuit. When the battery pack drops to 4.1 volts, the circuit causes the pump to shut down, the timer to stop, and the LOW BATT LED to light. This limits further battery drain to just a few milliamperes, which, in turn, helps prevent deep discharging and battery pack damage upon recharging. It also helps prevent the invalidation of the sample being taken, because the timer stores the actual sample time and the flow rate is controlled up to the time of shut-down.
- The FLOW FAULT LED indicates operation of the flow blockage detection circuit. If the sample inlet (or the sampling device connected to the pump) is blocked, the FLOW FAULT LED lights until the cause of the flow fault is removed.
- The pump is normally factory-programmed so that a fault longer than 1.5 minutes will shut down the pump. The pump may be restarted from a flow fault shutdown by pressing the RUN/ HOLD switch. Restarting in this manner allows continuation of the sample period without having the timer reset to zero.
- The Flow Fault LED is lighted whenever the pump flow rate is more than  $\pm 0.1$  LPM different from the set-point. It is normal for it to be lighted briefly while the pump is started or when a new set-point is selected.

## Section 3 Operation

### Charging the Battery Pack

Use any Omega™ charger (for example: P/N 494716, 495965, 800525 or 801759) for charging the battery pack. Remove the protective rubber plug and charge the battery pack for 14 to 16 hours. (Note that charging for longer periods will not reduce battery life, provided the charging is performed at room temperature.) The battery pack can be charged with the pack removed from the pump. Always replace the rubber plug after charging and before using the pump to prevent water entry into the jack.

#### **WARNING**

Do not charge the battery pack in areas that may contain a flammable mixture of combustible gases, vapors, or dust and air; otherwise, an explosion may occur because a source of ignition exists during charging.

#### **CAUTION**

Use only an MSA Omega (Ω) charger from MSA to charge the pump.

### Operating Time

The maximum expected operating time for a pump with a fully charged battery pack depends on:

1. The selected flow rate.
2. The vacuum load imposed by the sampling device.
3. The temperature.
4. The age of the battery pack.




Figure 3-1. Typical Operating Time Graph

See FIGURE 3-1 for approximate operating times. The shaded area shows operating loads and flow rates within the pump specifications. The example shown with dashed lines is for a pump set for 2.0 LPM with a sampling load of 15"; the expected maximum operating time would be 11.5 hours. This figure is based on room temperature operation with a new pack. At 0 degrees Centigrade, the operating time will be reduced by 10%, 20% at -20oC. After several hundred charge/discharge cycles, the pack capacity may be reduced by 20%.

### Personal/Area Sampling

The ESCORT ELF Pump is designed for either personal or area sampling of ambient air. It automatically provides a constant volumetric flow rate of the sample air through the sampling device (filter disc, impinger, or absorbent tube) to measure the concentration of airborne mists, dusts, particulates, gases, and vapors in the workplace.

## Operating the Pump

1. Charge the battery pack for 16 hours using the MSA Omega ( $\Omega$ ) Charger.
  - Read the WARNING on the battery pack.
2. Connect the desired sampling device to the inlet fitting.
3. Press ON/OFF button until the RUN/HOLD LED lights.
  - The Flow Fault and Low Bat LEDs will then light. During the time these LEDs are lighting, a number from 0 to 999 will be displayed. This is the total of the pump's operating hours since its last calibration.
  - When all three LEDs are lighted, the display changes to **8.88 LPM/MINS**, to show all segments are functional.
  - The pump will then begin operation. The LOW BAT LED will be dark if the battery voltage is above 4.1 volts. The Flow Fault LED will be dark when the flow rate is within 0.1 LPM of the setpoint.
4. Use the  $\uparrow$  and  $\downarrow$  switch buttons to adjust the flow setpoint if a new flow rate is desired. When either button is pressed:
  - RUN/HOLD LED will be dark
  - Display will show the flow setpoint being stepped up or stepped down to the new setpoint.
5. The RUN/HOLD button may be pressed to interrupt sampling without causing the timer to reset to zero.
6. Press the ON/OFF button at the end of sampling.
  - Total sample minutes will be on the display and will remain until the pump is turned ON again.
7. Check calibration monthly (every 200 hours of use for coal mine dust sampling).
8. Operate the pump with a sampling device connected to the inlet. Operation without a sampler attached will reduce the life of the pump inlet filter. Operation at very low flow rates may be unstable without an attached sampling device, such as a charcoal tube.

## Section 4 Routine Maintenance

### Periodic Maintenance

#### Checking the Inlet Filter

The pump inlet contains dust and water filters to protect the pump from particles and water in the sample air (FIGURE 4-1). If the filters become clogged, the sample flow may be blocked or an extra load placed on the pump; therefore, check the filters regularly.




Figure 4-1. Checking the Inlet Filter

#### Section 4, Routine Maintenance

---

The frequency of the checks should depend on the amount of pump usage and the concentration of particles allowed to enter the pump. Usually, only the dust filter needs to be replaced. The Teflon water filter should rarely need to be replaced. The water filter is very fragile and must be handled with care. Even a tiny pin hole will destroy its function. The filter frit should never need to be replaced if the other filters are maintained.

#### **Filter Replacement**

1. Remove the four screws holding the filter cover and O-ring.
2. Replace the filter with a new one.
3. Re-assemble the O-ring and cover.

#### **Frit Replacement**

1. Stab the frit center with a small screwdriver, and lift it out.
2. Press in a new frit.
3. Re-assemble the Teflon and dust filters, O-ring, and cover.

#### **Battery Pack Replacement**

*(FIGURE 4-2 illustrates the battery pack.)*

1. Remove the two screws securing the battery pack to the case.
2. Separate the pack from the case.
3. Make sure that the O-ring is in place on the replacement pack. Then, slide the pack into the pump case while pressing the case front and back to make sure the case edges go inside the edges of the pack.
4. Insert the two screws and tighten.

\* Teflon is a trademark of the du Pont Company






Figure 4-2. Replacing the Battery Pack

## Section 5

# ELF Sensor Calibration

1. Check pump inlet filter for dust; replace if heavily loaded.
2. Turn ON the pump and allow it to reach its flow rate setting.
3. If the pump is not set for 2.50 LPM, set it to 2.50.
4. Allow the pump to operate for 10 to 15 minutes at 2.50 LPM. To check for leaks, temporarily block the pump inlet; 0.02 LPM or less should be displayed. If not, check the inlet filter cover and o-ring for correct assembly.
5. Leave the pump set for 2.50 LPM and turn OFF the pump.
6. Connect a primary calibration standard to the pump.
7. Turn ON the pump; as the pump goes through its self-check sequence, press and hold the ON/OFF and RUN/HOLD switches simultaneously until the display reads CAL. Immediately release both buttons.

NOTE: Failure to release both buttons will turn OFF the pump.

- The display will show CAL and a countdown sequence of numbers from 9 through 0; thereafter, it will alternately display CAL and 2.50 LPM.
8. Operate the calibration standard and obtain at least six readings which are very close to one another.
  9. Use the  $\uparrow$  and  $\downarrow$  switch buttons to step the pump display up or down until it agrees exactly with the average of the six readings.
  10. Turn OFF the pump; the ELF sensor is now calibrated. Repeat monthly or every 200 hours of use.

*Section 5, ELF Sensor Calibration*

---

11. When you next turn ON the pump, the operating hours will be reset to **0** and be displayed during the lighting of the FLOW FAULT and LOW BAT LEDs.

The BIOS DryCal should be used to calibrate or check the flow rate of an MSA Escort ELF pump only if an isolating flow restrictor (e.g., a filter or an orifice such as P/N 632646) providing at least 10" WC is placed in line between the pump and the calibrator. Failure to use such an isolation technique can cause a calibration inaccuracy on the order of 2% and is not recommended.

## **Section 6 ELF Sensor Calibration for Pumps used in the U.S. Government Mine Safety and Health Administration (MSHA) Coal Mine Dust Sampling Program**

1. Check pump inlet filter for dust; replace if heavily loaded.
2. Turn ON the pump and allow it to reach its flow rate setting.
3. If the pump is not set for 2.00 LPM, set it to 2.00.
4. Allow the pump to operate for 10 to 15 minutes at 2.00 LPM. To check for leaks, temporarily block the pump inlet; 0.02 LPM or less should be displayed. If not, check the inlet filter cover and o-ring for correct assembly.
5. Leave the pump set for 2.00 LPM and turn OFF the pump.
6. Connect a primary calibration standard to the pump.
7. Turn ON the pump; as the pump goes through its self-check sequence, press and hold the ON/OFF and RUN/HOLD switches simultaneously until the display reads CAL. Immediately release both buttons.

NOTE: Failure to release both buttons will turn OFF the pump.

- The display will show CAL and a countdown sequence of numbers from 9 through 0; thereafter, it will alternately display CAL and 2.00 LPM.

*Section 6, ELF Sensor Calibration for Pumps used in  
MSHA Coal Mine Dust Sampling Program*

---

8. Operate the calibration standard and obtain at least six readings which are very close to one another.
9. Use the ↑ and ↓ switch buttons to step the pump display up or down until it agrees exactly with the average of the six readings.
10. Turn OFF the pump; the ELF sensor is now calibrated. Repeat every 200 hours of use .
11. When you next turn ON the pump, the operating hours will be reset to **0** and will be displayed during the lighting of the FLOW FAULT and LOW BAT LEDs.

## Section 7 Repairs and Replacement Parts

### Troubleshooting

TABLE 7-1, "Troubleshooting Guidelines," lists the symptoms of the most common problems; it also lists their probable cause(s) and the action required to correct each problem. Use the guidelines if you cannot calibrate the ESCORT ELF Pump or if the pump does not operate properly. If you cannot resolve a problem by using the guidelines, call 1-800-MSA-2222 to locate a local MSA Repair Center.

#### **⚠ WARNING**

**Use only genuine MSA replacement parts when performing the maintenance procedures described in this manual. Failure to do so may seriously impair instrument performance. Repair or alteration beyond the scope of these maintenance instructions or by anyone other than an MSA-trained service person could cause the product to fail to perform as designed, and persons who rely on this product for their safety could sustain severe personal injury or death.**

### Corrective Maintenance

When an inoperative part is located by using TABLE 7-1, Troubleshooting Guidelines, replace it according to one of the replacement procedures later in this section. Also refer to "Obtaining Replacement Parts" later in this section for information on how to order the necessary part from MSA.

Section 7, Repairs and Replacement Part

<b>Table 7-1. Troubleshooting Guidelines</b>		
<b>SYMPTOM</b>	<b>PROBABLE CAUSE</b>	<b>CORRECTIVE ACTION</b>
ON/HOLD LED indicator turns OFF prematurely; FLOW FAULT LED Indicator may be ON or OFF and LOW BATT LED is turned ON	1. Inlet filter clogged or blocked with water	1. Replace filter according to "Checking the Inlet Filter"
	2. Battery pack is degraded	2. Install new pack on pump by performing procedure described under "Battery Pack Replacement"
	3. Operation beyond flow and load limits	3. Reduce flow or replace sampler with lower load device
ON/HOLD LED and FLOW FAULT LED indicators turned ON, and pump will not run or, if it does run, no flow is displayed on readout	1. Pump motor connector improperly plugged into PC board	1. Check connector
	2. Pressure sensor connector fault	2. Check connector. Verify five pins are plugged in
	3. Pump motor inoperative	3. Replace pump and motor drive assembly according to procedure under "Replacing the Pump and Drive Assembly"
	4. Pressure sensor or PC board inoperative	4. Replace sensor or PC board
When inlet is blocked, the flow indication is not 0.02 lpm or less	1. Sample flow leaks	1. Check for leaking tube connection or O-ring seal at the inlet filter cover
LED indicator on charger does not turn ON when plug on-line cord is inserted in 115 VAC outlet and plug on charging cord is inserted in jack on battery pack	1. Power source inactive	1. Check and correct cause of power loss
	2. Charger failure	2. Replace charger
	3. Battery pack failure	3. Replace battery pack by performing procedure under "Replacing the Battery Pack"
Desired flow rate cannot be obtained under heavy sampling device loads within regime of FIGURE 3-1	1. Inlet filter partially clogged	1. Replace filter according to instructions under "Checking the Inlet Filter"
	2. Leak exists in sample flow system	2. Check for leaking tube connection or O-ring at the inlet filter cover

### **Unplugging the Electrical Connectors**

Service procedures which require opening the ELF pump case require the unplugging of two electrical connectors:

1. Pull on the motor electrical connector to remove the motor wires from the printed circuit board.
2. Pull on the 5-pin ribbon cable to remove the connector from the ELF sensor.

### **Reattaching the Electrical Connectors**

1. When reattaching the motor connector, make sure the angular ramp at the end faces towards the latch projecting from the printed circuit board socket.

NOTE: The pump will operate with the connector installed the other way, but the above method is encouraged because the ramp and latch help keep the connector attached as the pump is knocked around during use.

2. When reattaching the connector to the ELF sensor, make sure pins #1 through #5 are straight and in line.

NOTE: If these pins are bent, use needle-nose pliers to straighten and align them. Pin #6 is intentionally cut off because it is not used in the ELF pump.

3. Pull the cable so that the end of the connector is about 7/8" above the printed circuit board.
4. Hold the pump face in the right hand and position your thumb and forefinger around the top left hand corner of the pump face.
5. Hold the connector with these two fingers and hold the pump case with the left hand.
6. Position the connector so that an end pin is just inside the funnel opening of the corresponding pin socket.
7. Gradually tilt the connector to get the next pin just inside its socket, and repeat this process until all five pins are just inside their corresponding sockets.
8. Slowly press the connector onto the pins until they "bottom out."



## Section 7, Repairs and Replacement Part

---

9. Inspect the connector at the top and bottom to make sure all pins are correctly inserted.

### **Pump & Drive Assembly, Outlet Dampener, or Pressure Sensor Replacement**

1. Remove two screws securing the battery pack to the case.
2. Remove the battery pack.
3. Remove the two screws securing the pump case.
4. Pull the 5-pin ribbon connector from the pressure sensor.
5. Pull the motor electrical connector from the PC board.
6. Remove the two screws securing the pump mounting collar to the back of the case.
7. Lift out the pump and drive while removing the inlet dampener connection from the fitting.

NOTE: A drop of soap solution (SNOOP<sup>®</sup>) "worked in" at the end of the rubber tube makes removal easier and will prevent tearing the rubber tube.

8. Remove the two screws securing the pressure sensor.
9. Remove the pressure sensor and be careful not to drop it, even to the table top.
10. Remove the outlet dampener if it is to be replaced.
11. Install the replacement pump and drive, outlet dampener or pressure sensor by reversing this procedure.

NOTE: Wetting the end of the outlet dampener will make sliding it over the sensor body easier. Make sure both cuffs are completely in the grooves.

NOTE: Tighten the upper motor collar screw before tightening the lower screw when installing the new pump and drive.

### **Printed Circuit Control Board Replacement**

1. Remove the two screws securing the battery pack.
2. Remove the battery pack.

---

\*SNOOP is a trademark of Nupro Company

*Section 7, Repairs and Replacement Part*

---

3. Remove the two screws securing the pump case.
4. Pull the connector from the pressure sensor.
5. Pull the motor electrical connector from the printed circuit board.
7. Remove and save the three screws, two washers and spacer securing the PC board to the pump face.
8. Install the replacement printed circuit board by reversing this procedure.

NOTE: Be sure the battery connector is mounted with the black wire towards the top of the case.

### **Obtaining Replacement Parts**

The ESCORT ELF Pump parts and part numbers are listed in TABLE 7-2. To obtain parts, service, or information in the U.S., call 1-800-MSA-2222 to find the nearest customer service center. To reach MSA International, call 1-412-967-3000.

Section 7, Repairs and Replacement Part




Figure 7-1. Replacement Parts

Section 7, Repairs and Replacement Part

<b>Table 7-2. Replacement Parts List</b>		
<b>FIGURE 7-1 ITEM NO.</b>	<b>PART/COMPONENT</b>	<b>PART NO.</b>
1	Pump and Flow Assembly, complete	804661
2	Collar	800025
3	Printed Circuit-Board Assembly	813551
4	Pump Face Assembly	813297
5	Screw	636493
6	O-ring	636602
7	Screw	636414
8	Belt Clip	636293
9	Screw	636416
10	Screw	636415
11	Spacer	628852
12	Lockwasher	64095
13	Switch Cover	802381
<b>FIGURE 7-2 ITEM NO.</b>	<b>PART/COMPONENT</b>	<b>PART NO.</b>
14	Pump and Drive less Pressure Sensor	805285
15	Flow Sensor Only	805286
16	Replacement Sensor Only	805284
17	Motor and Connector Assembly	805296
18	Eccentric and Bearing Assembly	805046
19	Pump Block and Valves Assembly	805360
20	Inlet Dampener	803816
21	Screws	637140
22	Outlet Dampener	804663
FIGURE 4-1	Screw	636418
	Filter Cover	497393
	O-ring	637009
	Inlet dust filter (pack of 5)	808935
	Filter, Teflon	802897
FIGURE 4-2	Filter Frit	800303
	Battery Pack (includes O-ring & Plug)	10087242
	O-ring for Battery Pack	636603
not shown	Charge Jack Plug	804158
	Instruction Manual	813549
	Screwdriver	636913
	Leather Case (optional)	811741
	Upgrade Kit (includes printed circuit board and pump face assemblies)	814029

Section 7, Repairs and Replacement Part




Figure 7-2. Replacement Parts (cont.)

<b>Table 7-2. Replacement Parts List (cont.)</b>	
<b>PART/COMPONENT</b>	<b>PART NO.</b>
Kit, Pump Maintenance Parts	802922
Belt Clips	
Filter Cover	
Screws (filter cover)	
O-Rings (battery pack)	
Screws (belt clip)	
Screws (case)	
Polyethylene Discs	
O-Rings (filter cover)	
Inlet Filters	