

Bonnet, Shroud, and Faceshield

Shroud P/N 10041994
1010 Bonnet P/N 10041992
660C Bonnet P/N 10041993
6" Gold-Coated Faceshield P/N S606G

installation instructions

APPLICATION

With proper installation of the gold-coated 6" faceshield (P/N S606G) and the bonnet and shroud to the helmet, the helmet will be compliant with NFPA 1971-2007.

Shroud (P/N 10041994) can only be used with the Cairns 1010, Cairns 1044, Classic™ 1000, 660C Metro, Invader 664, or 990 Intruder helmets.

Bonnet (P/N 10041992) can only be used with the Cairns 1010, Cairns 1044 or Classic 1000 helmets.

Bonnet (P/N 10041993) can only be used with the 660C Metro, Invader 664, or 990 Intruder helmets.

The gold-coated 6" faceshield (P/N S606G) can be used with the Cairns 1010, Cairns 1044, Classic 1000, 660C Metro, Invader 664, or 990 Intruder helmets.

PROXIMITY BONNET INSTALLATION

- Insert helmet D-ring through slot in bonnet.
- Beginning at rear D-ring, pull bonnet over helmet shell and over the outside of the helmet shell.
- Secure hook and loop tabs around faceshield mounting brackets.
- Replace old faceshield with new gold-coated faceshield (P/N S606G). Faceshield label must say "NFPA 1971-2007 EDITION".
- Pivot the faceshield to ensure it doesn't snag on the outer cover.

SHROUD INSTALLATION

- Begin at rear of the helmet and attach the shroud to the inside of the helmet with the hook and loop.
- Slip the chinstrap cords through the slots in the shroud.

INSPECTION

Ensure shroud is properly attached to helmet before and after each use.

⚠ WARNING

Read all instructions and warnings before wearing this helmet.

Users in the field cannot test performance properties of NFPA 1971-2007 EDITION.

After removal from the wearer, the helmet should be inspected for damage and soiling after each use.

The helmet should be adjusted by means of the adjustment points provided to permit a proper fit that does not interfere with the SCBA while in use. These adjustments should be done prior to actual fire fighting activities.

Failure to follow these instructions could result in serious injury or death.

CLEANING

Remove the bonnet and shroud. Clean the bonnet with mild soap or detergent. Wash the shroud in warm, soapy water, rinse thoroughly with clean water, and air dry at room temperature. Clean the faceshield with mild detergent, rinse thoroughly with clean water, and dry with a soft cloth.

Users should not wear helmets that are not thoroughly cleaned and dried.



Note: Photo does not show faceshield.



For More Information, call 1-800-MSA-2222 or Visit Our Website at www.MSAnet.com

MSA
The Safety Company

MINE SAFETY APPLIANCES COMPANY
PITTSBURGH, PENNSYLVANIA, U.S.A. 15230