



## CERTIFIED AIRMASK REPAIR EDUCATION PROGRAM

### MSA MMR AIR MASK REPLACEMENT PARTS KITS

#### PN 494710 – MMR Custom 4500<sup>®</sup> Air Mask User Maintenance Parts Kit

Kit Includes:

<u>Qty</u>	<u>Part Number</u>	<u>Description</u>
6 ea.	83731	Lock Nut
10 ea.	628976	O-Ring
6 ea.	488858	Valve Insert
6 ea.	803134	Spring, Diaphragm
6 ea.	488740	Screw, Adjusting
20 ea.	635244	Retaining Ring
20 ea.	635242	O-Ring
6 ea.	80416	Insert, Bottle Valve Tube
6 ea.	488859	Valve Stem
10 ea.	630926	O-Ring
6 ea.	83831	Spring
10 ea.	488860	Washer, Valve Stem
6 ea.	488741	Thrust Ring
6 ea.	637089	Jam Nut
10 ea.	637904	Screw
6 ea.	482226	Kit, Blow Out Disc
4 ea.	473254	Safety Plug
4 ea.	91728	Handwheel
6 ea.	488785	Cap, Bypass
6 ea.	492238	Spring, Shutoff
6 ea.	488755	Ring, Spacer
4 ea.	803135	Base, Shutoff
6 ea.	488862	Packing Gland
6 ea.	488783	Diaphragm
6 ea.	813713	Cap, Shutoff
4 ea.	813712	Pushbutton, Shutoff
6 ea.	495277	Handwheel Assembly
4 ea.	800685	Spring
2 ea.	490676	Hose Assembly
1 ea.	635767	Cabinets, Parts Station 16½" X 12" X 6", 26 Drawers
1 ea.	495130	Labels, Drawer
6 ea.	638141	Ring, Retaining Spiral



## CERTIFIED AIRMASK REPAIR EDUCATION PROGRAM

### PN 494709 – MMR Ultralite® Air Mask User Maintenance Parts Kit

#### Kit Includes:

<u>Qty</u>	<u>Part Number</u>	<u>Description</u>
6 ea.	83731	Lock Nut
10 ea.	628976	O-Ring
6 ea.	488858	Valve Insert
6 ea.	803134	Spring, Diaphragm
6 ea.	488740	Screw, Adjusting
20 ea.	635244	Retaining Ring
20 ea.	635242	O-Ring
6 ea.	80416	Insert, Bottle Valve Tube
6 ea.	488859	Valve Stem
10 ea.	68542	O-Ring
6 ea.	83831	Spring
10 ea.	488860	Washer, Valve Stem
6 ea.	488741	Thrust Ring
6 ea.	637089	Jam Nut
10 ea.	637904	Screw
6 ea.	482225	Kit, Blow Out Disc
4 ea.	68550	Safety Plug
4 ea.	91728	Handwheel
6 ea.	488785	Cap, Bypass
6 ea.	492238	Spring, Shutoff
6 ea.	488755	Ring, Spacer
4 ea.	803135	Base, Shutoff
6 ea.	488862	Packing Gland
6 ea.	488783	Diaphragm
6 ea.	813713	Cap, Shutoff
4 ea.	813712	Pushbutton, Shutoff
6 ea.	495277	Handwheel Assembly
4 ea.	800685	Spring
2 ea.	490676	Hose Assembly
1 ea.	635767	Cabinets, Parts Station 16 ½" X 12" X 6", 26 Drawers
1 ea.	495129	Labels, Drawer
6 ea.	638141	Ring, Retaining Spiral



## CERTIFIED AIRMASK REPAIR EDUCATION PROGRAM

### PN 494712 Custom 4500<sup>®</sup> Certified Maintenance Parts Kit

#### Kit Includes:

<u>Qty.</u>	<u>Part Number</u>	<u>Description</u>
6 ea.	490605	Lock Nut
10 ea.	635311	Backup Ring
20 ea.	634669	O-Ring
10 ea.	490645	Washer
20 ea.	634670	O-Ring
10 ea.	634672	Backup Ring
20 ea.	630493	O-Ring
20 ea.	634667	O-Ring
12 ea.	68523	Retaining Ring
6 ea.	85052	Piston Plug
20 ea.	66395	O-Ring
20 ea.	635954	O-Ring
20 ea.	635953	O-Ring
20 ea.	85053	Valve Pellet
4 ea.	488811	Locknut, Bypass
10 ea.	635243	O-Ring
10 ea.	635240	O-Ring
10 ea.	488810	Screw, Guide, Bypass
10 ea.	635241	O-Ring
10 ea.	488808	Screen, Bypass
6 ea.	488782	Diaphragm, Power Stage
10 ea.	634814	O-Ring
6 ea.	488799	Seat
6 ea.	635032	Spring
6 ea.	488855	Spring
6 ea.	488854	Spring
10 ea.	85055	Spring
6 ea.	474352	Spring
6 ea.	488853	Piston
4 ea.	474369	Valve, Adjuster
4 ea.	488833	Screw, Adjusting
6 ea.	488798	Piston Shaft
4 ea.	488816	Cap
4 ea.	85049	Piston
4 ea.	85051	Striker
4 ea.	816951	Slide
6 ea.	490656	Spool
6 ea.	488779	Spring, Bypass
4 ea.	488812	Sleeve, Bypass
4 ea.	488796	Spool, Power Stage
4 ea.	803417	Valve & Lever Core Assembly
1 ea.	627989	Cabinet, 18 1/4" X 8 5/8" X 6 3/8"
1 ea.	495132	Labels, Drawers



## CERTIFIED AIRMASK REPAIR EDUCATION PROGRAM

### PN 494711 Ultralite® Certified Maintenance Parts Kit

#### Kit Includes:

<u>Qty.</u>	<u>Part Number</u>	<u>Description</u>
6 ea.	490605	Lock Nut
10 ea.	635311	Backup Ring
20 ea.	634669	O-Ring
10 ea.	490645	Washer
20 ea.	634670	O-Ring
10 ea.	634672	Backup Ring
20 ea.	630493	O-Ring
20 ea.	634667	O-Ring
12 ea.	68523	Retaining Ring
6 ea.	85052	Piston Plug
20 ea.	66395	O-Ring
20 ea.	635954	O-Ring
20 ea.	635953	O-Ring
20 ea.	85053	Valve Pellet
4 ea.	488811	Locknut, Bypass
10 ea.	635243	O-Ring
10 ea.	635240	O-Ring
10 ea.	488810	Screw, Guide, Bypass
10 ea.	635241	O-Ring
10 ea.	488808	Screen, Bypass
6 ea.	488782	Diaphragm, Power Stage
10 ea.	634814	O-Ring
6 ea.	488799	Seat
6 ea.	635032	Spring
6 ea.	488855	Spring
6 ea.	488854	Spring
10 ea.	85055	Spring
6 ea.	455941	Spring
6 ea.	488853	Piston
4 ea.	474369	Valve, Adjuster
4 ea.	488833	Screw, Adjusting
6 ea.	488798	Piston Shaft
4 ea.	488816	Cap
4 ea.	85049	Piston
4 ea.	85051	Striker
4 ea.	816951	Slide
6 ea.	490656	Spool
6 ea.	488779	Spring, Bypass
4 ea.	488812	Sleeve, Bypass
4 ea.	488796	Spool, Power Stage
4 ea.	803417	Valve & Lever Core Assembly
1 ea.	627989	Cabinet, 18 1/4" X 8 5/8" X 6 3/8"
1 ea.	495131	Labels, Drawers