

Safe Escape™ Respirator

DONNING



1 Remove the lid from the Hextreme™ Case by grasping at the label that reads "Lift Lid to Open".



2 Remove the packaged hood assembly from the Hextreme Case.



3 Open the hermetically sealed bag by tearing the bag material at the designated tear notch located at the top of the bag.



4 Pull the Safe Escape Respirator assembly from the sealed bag. Remove the wrapping tissue, and if still attached, remove the white foam canister guard from the end of canister.



5 Unfold the Safe Escape Respirator and insert both hands through the neckseal into the elastic harness. With hands expanded, stretch the neck seal outward and pull over head.



6 If eyewear is worn, be sure to expand the neckseal outward far enough to clear the eyewear during donning.



7 Adjust the nosecup on the face. The nosecup must cover the nose and mouth for proper protection.



8 Adjust harness by grasping the back of the hood and pulling it into position so that the harness cradles the crown of the head.



9 Ensure the neckseal is sealed against neck. Nothing should come between the neckseal and the skin.



10 Pull the skirt of the hood down to cover the neckseal area.



MSA

The Safety Company
1-800-MSA-2222 www.MSAnet.com