



**CATEGORY II CERTIFICATION**

STC375E - REV 2 - 31.01.05



# DEXTRAM 375 - 376

**CE-Type Examination Certificates**

**DEXTRAM 375 : 0072/014/162/12/96/0681**

**DEXTRAM 376 : 0072/014/162/12/96/0681/Ex01 12 96**

**issued by the approved body nr. 0072**

I.F.T.H. – Av. Guy de Collongue - F-69134 ECULLY CEDEX

**These gloves conform to the provisions of Directive 89/686/EEC for protection against mechanical risks.**

# DEXTRAM 375 - 376

## DESCRIPTION AND GENERAL PROPERTIES

**Gauntlet cotton knit** gloves fully coated with **yellow nitrile rubber**.

**Curved fingers** and **contoured palm**.

**Smooth** external surface.

Guaranteed **silicone-free**.

Conform to the FDA (Food and Drug Administration) regulation for **food contact**.

Reference	Length (for all sizes) (in cm)*	Thickness in wrist area (in mm)*	Sizes available
Dextram 375	26	0.80	6 - 6 ½
Dextram 376	31		7 - 7 ½
			8 - 8 ½
			9 - 9 ½

\* nominal values

Standard packaging:

- **each pair** in printed polyethylene bag
- **50 pairs** per carton

## "CE"-TYPE EXAMINATION RESULTS



### PROTECTION AGAINST MECHANICAL RISKS

Levels of performance according to EN 388 standard.

**3 1 1 1**  
| | | |  
| | | | ↪ puncture resistance (0 to 4)  
| | ↪ tear resistance (0 to 4)  
| ↪ blade cut resistance (0 to 5)  
↪ abrasion resistance (0 to 4)

# DEXTRAM 375 - 376

## SPECIFIC ADVANTAGES

- Cotton lining offers extra comfort : working area totally seam-free.
- Excellent sensitivity and flexibility.
- High resistance to abrasion.
- Good protection against humidity and splashes of oil and grease.
- Products manufactured in a MAPA factory which is ISO 9001 certified.
- Recommended for persons sensitized to natural rubber proteins.

## MAIN FIELDS OF USE

- Painting
- Carpentry
- Handling small oily components
- Rubbing down and sanding
- Packaging
- Manufacturing of small electrical components (batteries, lamps)

## INSTRUCTIONS FOR USE

For enhanced safety and service life of the gloves :

- Store the gloves in their original packaging protected from direct light and heat sources.
- It is recommended to check that the gloves are suitable for the intended use, because the conditions of use at workplace may differ from the « CE »-type test.
- Put the gloves on dry, clean hands.
- It is not recommended for persons sensitized to dithiocarbamates and thiazoles to use these gloves.
- Rub over the gloves stained with oil or grease using a dry cloth before taking them off.

Caution: using the gloves or submitting them to another cleaning or laundering process can alter their performance levels.

- Ensure the inside of the gloves is dry before putting them on again.
- Inspect the gloves for snags or tears before reusing them.