

PROTECTION AND DEXTERITY



CATEGORY III CERTIFICATION

STC990E - REV 2 – 23.11.04.

CE 0334

SOLO 990

CE-Type Examination Certificate

0075/014/162/11/04/0204

issued by the approved body nr. 0075
C.T.C – F-69367 LYON CEDEX 07

Certificate of conformity of the Quality Assurance System
issued by the approved body nr. 0334
ASQUAL - 14, rue des Reculettes - F-75013 PARIS

These gloves conform to the provisions of Directive 89/686/EEC for protection against chemicals and micro-organisms within the limit of the recommendations hereafter.

57, rue de Villiers - B.P. 190
92205 NEUILLY SUR SEINE Cedex – France
Tél : (33) 1 49.64.22.00 - Fax : (33) 1 49.64.24.29

www.mapa-professionnel.com

MAPA (U.K.) Ltd
Unit A - Halesfield 14 – TELFORD TF7 4QR
Tel (01) 952.684.487 / Fax (01) 952 580 959

MAPA[®]
PROFESSIONNEL

SOLO 990

DESCRIPTION AND GENERAL PROPERTIES

White liquidproof gloves made of **vinyl (PVC)**.

Ambidextrous design.

Beaded cuff end.

Surface coated with **bio-absorbable powder.**

Conform to the FDA (Food and Drug Administration) and European regulations for **food contact.**

Thickness (at the cuff) : **0.12 mm** (nominal value)

Length (for all sizes) : **24 cm** (nominal value)

Sizes available : 6-6 ½ 7-7½ 8-8½ 9-9½

Standard packaging :

- **100 gloves** in printed cardboard box
- **10 boxes** per carton

"CE"-TYPE EXAMINATION RESULTS



LIQUIDPROOF GLOVES
According to EN 374 standard



**PROTECTION AGAINST
MICRO-ORGANISMS**
According to EN 374 standard

AQL (Acceptable Quality Level): **1.5%**

These gloves are not designed for long duration contact nor immersion in chemicals,
nor for protection against mechanical hazards.

Avoid contact with oils and grease.

SOLO 990

SPECIFIC ADVANTAGES

- Precision dexterity : reduced glove thickness.
- Easy to put on and take off.
- Protection adapted to short duration usage.
- For food handling.

MAIN FIELDS OF USE

- Laboratory work.
- Preparation of medicines.
- Preparation of cosmetics.
- Small parts assembly.
- Messy cleaning jobs.
- Routine use in hospitals and clinics.

INSTRUCTIONS FOR USE

For enhanced safety and service life of the gloves :

- Store the gloves in their original packaging protected from light and humidity, far from heat sources.
- Put the gloves on dry, clean hands.
- These gloves are designed for single use only.
- Do not touch the external side of the gloves when taking them off. Fold back the cuff end and pull them off while turning them inside out.